


AMERICAN SERIES JAZZ BASS 019-3400  
 AMERICAN SERIES JAZZ BASS FRETLESS 019-3408  
 AMERICAN SERIES JAZZ BASS V 019-3500



S-1 SWITCH VOLUME POT (UP & DOWN)

S-1 SWITCH UP	
NECK P.U. VOLUME	V1
BRIDGE P.U. VOLUME	V2
	← A (NECK)
	← B (BRIDGE)
A/B	CONNECTION

S-1 SWITCH DOWN	
MASTER VOLUME	V1
N/A	V2
	← A (NECK)
	← B (BRIDGE)
A+B	CONNECTION

V1 = VOLUME #1  
 V2 = VOLUME #2  
 MT = MASTER TONE  
 + = SERIES CONNECTION  
 / = PARALLEL CONNECTION



	PICKUP IS ON
	PICKUP IS OFF
A	PICKUP (NECK)
B	PICKUP (BRIDGE)